

Honeywell



LEVEL 6

HARDWARE

**MODEL 43/53
SYSTEMS
DESCRIPTION
MANUAL**

This document and the information contained herein are confidential to and the property of Honeywell Information Systems Inc. and are made available only to Honeywell employees for the sole purpose of maintaining Honeywell's products. This document, any copy thereof and the information contained herein shall be maintained in strictest confidence; shall not be copied in whole or in part except as authorized by the employee's manager; and shall not be disclosed or distributed (a) to persons who are not Honeywell employees, or (b) to Honeywell employees for whom such information is not necessary in connection with their assigned responsibilities. Upon request, or when the employee in possession of this document no longer has need for the document for the authorized Honeywell purpose, this document and any copies thereof shall be returned to the employee's manager. There shall be no exceptions to the terms and conditions set forth herein except as authorized in writing by the responsible Honeywell Vice President.

This document and the information contained herein are confidential to and the property of Honeywell Information Systems Inc. and are made available only to Honeywell employees for the sole purpose of maintaining Honeywell's products. This document, any copy thereof and the information contained herein shall be maintained in strictest confidence; shall not be copied in whole or in part except as authorized by the employee's manager; and shall not be disclosed or distributed (a) to persons who are not Honeywell employees, or (b) to Honeywell employees for whom such information is not necessary in connection with their assigned responsibilities. Upon request, or when the employee in possession of this document no longer has need for the document for the authorized Honeywell purpose, this document and any copies thereof shall be returned to the employee's manager. There shall be no exceptions to the terms and conditions set forth herein except as authorized in writing by the responsible Honeywell Vice President.

MODEL 43/53
SYSTEMS DESCRIPTION
MANUAL

Document No. 71010316-200 Order No. FN36, Rev. 1

This manual has been revised to the -200 level.
It supersedes all previous issues.

CONTENTS

Section		Page
I	INTRODUCTION	1-1
	1.1 Applicable Documents	1-1
	1.2 System Overview	1-3
	1.3 System Components	1-4
	1.4 Physical Characteristics	1-6
	1.4.1 Rack-Mountable System	1-6
	1.4.2 Office Furniture Package System	1-7
	1.4.3 Tabletop System	1-7
II	SYSTEM DESCRIPTION	2-1
	2.1 System Configurations	2-1
	2.2 System Elements	2-3
	2.2.1 Central Processor	2-3
	2.2.1.1 Double Word Fetch Feature	2-7
	2.2.1.2 SAF and LAF Addressing	2-7
	2.2.1.3 Stack Management	2-8
	2.2.1.4 Queue Management	2-9
	2.2.1.5 Interrupts and Traps	2-11
	2.2.1.6 Dedicated Memory	2-14
	2.2.1.7 Quality Logic Test	2-16
	2.2.1.8 Control Panels	2-16
	2.2.1.9 Operational Modes	2-20
	2.2.1.10 Multiple Central Processors	2-20
	2.2.2 Model 53 System Differences	2-22
	2.2.2.1 Cache Memory Unit	2-22
	2.2.2.2 Memory Management Unit	2-24
	2.2.3 Main Memory	2-25
	2.2.3.1 MOS Memory	2-26
	2.2.3.2 Core Memory	2-28
	2.2.4 System Megabus	2-28
	2.2.4.1 Chassis Parity	2-31
	2.2.4.2 Megabus Operations	2-32
	2.2.5 Peripheral Devices	2-38
	2.2.6 Central System Power Supply	2-41
	2.2.7 Power Distribution Unit	2-41
	2.3 System Options	2-42
	2.3.1 System/Processor Options	2-42
	2.3.1.1 Memory Management Unit Option	2-42

CONTENTS

Section		Page
	2.3.1.2 Scientific Instruction Processor Option	2-42
	2.3.1.3 Writable Control Store Option	2-43
	2.3.1.4 Intersystem Link Option	2-46
	2.3.1.5 Multiline Communications Processor Option	2-47
2.3.2	Memory Options	2-49
2.3.3	Peripheral Controller Options	2-49
	2.3.3.1 Multiple Device Controller	2-51
	2.3.3.2 Magnetic Tape Controller	2-51
	2.3.3.3 Medium Performance Disk Controller	2-54
	2.3.3.4 General Purpose Interface Controller Option	2-54
2.3.4	Special Options	2-56
	2.3.4.1 Memory Save Power Supply	2-56
	2.3.4.2 Level 6 Extender Board Option	2-56
	2.3.4.3 Portable Control Panel Option	2-56
III	SYSTEM PARTS CATALOG	3-1

ILLUSTRATIONS

Figure		Page
1-1	Typical Rack-Mountable System	1-10
1-2	Typical Office Furniture Package System	1-11
1-3	Typical Tabletop System	1-11
1-4	Typical Configurations and Operations	1-12
1-5	Cabinetry Panels	1-13
1-6	Typical Rack-Mountable System Component Area	1-14
1-7	Typical Five-Board System Chassis	1-15
1-8	Typical 10-Board System Chassis and Power Supplies	1-15
1-9	Memory Save Power Supply	1-16
1-10	Typical Power Distribution Unit	1-17
1-11	Typical Controller/Processor Boards and Adapter Boards Layout	1-18
1-12	Office Furniture Package Control Panel Locations	1-19
2-1	Model 43 and Model 53 Basic System	2-2
2-2	Typical System Configurations	2-4
2-3	CPU Major Block Diagram	2-5
2-4	Stack Structure	2-9
2-5	Queue Management	2-10
2-6	Trap/Interrupt Linkage	2-12

ILLUSTRATIONS

Figure		Page
2-7	Dedicated Memory Locations	2-15
2-8	System Control Panels	2-17
2-9	Control Panel Configuration Switch Access	2-19
2-10	System Start Up/Initialization Sequence	2-21
2-11	Multiprocessor Set Up	2-22
2-12	Cache Memory/CPU Block Diagram	2-23
2-13	Model 53 System Cache Memory and Central Processor Boards	2-24
2-14	Memory Management Unit Block Diagram	2-25
2-15	Typical Memory Controller Intermediate Block Diagram	2-27
2-16	Megabus Chassis Connectors	2-31
2-17	Chassis Controller Board Slot Position	2-33
2-18	Address and Data Formats for Megabus Operations	2-34
2-19	SIP Functional Block Diagram	2-44
2-20	Writable Control Store Option Block Diagram	2-45
2-21	Micro Code Analyzer Front Panel	2-45
2-22	Intersystem Link Connecting Two Megabuses	2-46
2-23	Multiline Communications Processor Configuration	2-48
2-24	Multiple Device Controller Major Block Diagram	2-52
2-25	Magnetic Tape Controller Major Block Diagram	2-53
2-26	Medium Performance Disk Controller Major Block Diagram	2-55
3-1	Tabletop Cover Assembly	3-17
3-2	Five Board Tray Assembly	3-19
3-3	Wrapper for 5-Board Tray	3-22
3-4	Ten Board Tray Assembly	3-24
3-5	Wrapper for 10-Board Tray	3-27
3-6	Dress Panel Assembly for High Rack Cabinet System	3-29
3-7	Vertical Mount Control Panel Assembly	3-32
3-8	Tilt-Up Control Panel Assembly	3-33
3-9	Keyboard Assembly for Full Control Panel	3-34
3-10	Basic Control Panel Assembly	3-35
3-11	Micro Code Analyzer for WCS Option	3-36
3-12	Megabus Expansion Cable	3-37
3-13	Cache Memory Interface Cable	3-38

TABLES

Table		Page
1-1	System Components	1-4
1-2	Rack-Mountable System Characteristics	1-8
2-1	Trap Vectors and Events	2-13
2-2	Megabus Interface Signals	2-29
2-3	Model 43 and Model 53 Memory Controllers and Memory-Pacs	2-50
3-1	Desk Top Assembly Parts 60129859	3-4
3-2	Tray Assembly Parts 60128223	3-6
3-3	Wrapper Assembly Five-Card Parts 60128224	3-7
3-4	Tray Assembly 10-Card Parts 60131953	3-8
3-5	Wrapper Assembly 10-Card 60128290	3-9
3-6	Dress Panel Assembly Parts 60129856	3-10
3-7	Vertical Mount Control Panel Parts 60130092	3-11
3-8	Tilt Up Control Panel Assembly 60132017	3-12
3-9	Keyboard Assembly Parts for Full Panel 60131949	3-13
3-10	Basic Control Panel Assembly Parts 60133633	3-14
3-11	Micro Code Analyzer Assembly Parts 60132206	3-15